

FIG. 1

TUNE TO RECEIVE A SELECTED BROADCAST CHANNEL IN RESPONSE TO A USER CHANNEL CHANGE COMMAND TO TUNE TO A DEFINED TRANSMISSION CHANNEL

A PLURALITY OF PROGRAM GUIDES ARE AVAILABLE ON THE USER SELECTED TRANSMISSION CHANNEL. SELECT A PARTICULAR PROGRAM GUIDE, IN ACCORDANCE WITH THE PREDETERMINED PROGRAM GUIDE PRIORITY, TO ASSOCIATE WITH THE USER SELECTED TRANSMISSION CHANNEL.

UPDATE A DATABASE IN A VIDEO DECODER TO ASSOCIATE THE USER SELECTED TRANSMISSION CHANNEL WITH THE AVAILABLE PROGRAM GUIDE (OR SELECTED PROGRAM GUIDE IN THE CASE THAT MORE THAN ONE IS AVAILABLE).



115

ACQUIRE AND ASSEMBLE THE DATA PACKETS COMPRISING THE PROGRAM GUIDE ASSOCIATED WITH THE USER SELECTED PROGRAM CHANNEL	
	120

DISPLAY AVAILABLE PROGRAMS AND ASSOCIATED BROADCAST TIMES (FOR THE USER SELECTED TRANSMISSION CHANNEL) IN A USER VIEWABLE PROGRAM GUIDE LISTING	
	125

END 135

[illegible]







FIG. 5

FIGURE 6

5/8



6/8




FIG. 7





FIG. 8

FIGURE 9

7/8



[illegible]

8:13 P.M. 14 APRIL 1997

